







- If you need to mount the laser onto a firearm, make sure the firearm is unloaded before installation.
- Always use safe handling practices at all times. Do not operate the laser if the unit is defective or the cover or seal is damaged.
- Avoid direct eye contact with the laser and its possible bright reflection as this may cause serious eye injury
- Do not direct the laser at any aircraft, public transportation, or other objects of safety concern. This is very dangerous and may be considered a felony.
- Ensure the laser cannot be turned on when stored or being transported. If the laser is activated while in a case, container, etc. it can become a fire hazard and cause damages.
- Examine the battery quality and appearance before use and make sure no battery leakage or deformation is present. Dispose appropriately when necessary and replace with a new battery.
- In general, batteries are pre-charged by the manufacturer and cannot be recharged. Recharging can cause battery leakage and in some cases, cause a high-pressure rupture.
- Inadvertent charging can occur if a battery is installed backwards.
- Remove battery from the laser if storing away for a prolonged period of time. Leaving the battery in without use for a prolonged period may cause damages. Keep battery in a cool and dry environment.
- Do not use a rechargeable battery in this laser. Only use the correct type of battery specified for the laser.
- Never deliberately short circuit the battery. Prolonged short circuiting will cause the battery to drain and potentially result in a significant increase in temperature.
- Do not transport the laser with the battery installed enclosed in an environment that may
 experience high temperatures and or is not well ventilated, such as, the inside of a car trunk.
- Keep battery compartment clean from debris.
- Lithium batteries can explode and cause harm if disassembled, shorted, recharged, exposed to water, fire, or high temperatures. Do not place loose batteries in pockets, purse, etc.
- Do not mix new and old batteries together and or use different battery types together
- Do not store batteries with hazardous or combustible materials. Storé in a cool, dry, ventilated area.
- Follow all applicable laws and regulations for disposal.

Do not use rechargeable batteries unless explicitly specified in this manual.

1

Component Illustration















- Battery Installation 1. Remove the Battery Compartment Cap by turning it counterclockwise using a coin (Fig. 1).
- 2. Insert the 1/3N Battery into the compartment with the + side facing upward (Fig. 2).
- 3. Reinstall the Battery Compartment Cap by turning it clockwise using a coin until securely tightened.

On/Off Operations (Fig. 3)

1. Constant On/Off

Pushing either switch upward once will keep the laser on. Another push of either switch will turn the laser off.

2. Momentary On/Off

Pushing and holding either switch downward will turn the laser on for the duration in which you hold it down for.

Installing the Laser

Steps 1 and 2 may be optional

- 1. Remove the two allen screws closest to the ambidextrous operating Switches using the included allen wrench by turning them counterclockwise in order to remove the pre-installed Posi-lock Tab, should you need to use one of the other included Posi-lock Tabs for your particular firearm and preferred laser positioning. (Fig. 4).
- 2. Install the Posi-lock Tab that is best suited for your particular firearm and laser positioning with its respective number of allen screws, turning the allen wrench clockwise until securely tightened.
- 3. Loosen the locking plate screw by turning it counterclockwise with the included allen wrench until there is enough clearance for the integral mounting deck to seat evenly on your firearm's accessory rail (Fig. 5).
- 4. Retighten the locking plate screw by turning the allen wrench clockwise until securely tightened (Fig. 6). Recommended torgue value: 25 inch-lb.

Do not over tighten any installation screws as you may cause damage to the main body of the laser or firearm.

Specifications

Item # (Model)	SCP-LS279S
Length	1.72" (43.8mm)
Body Diameter	1.15" (29.3mm)
Range	546.8yds (500m)
Weight with Battery	2.1oz (61g)
Structure & Adjustment	TS & 4 Points
Windage/Elevation Adjustment Range	31"@100 yds
Туре	CLASS 3R
Output Power	2 - 4.5mw
Wavelength	522 - 542nm
Beam Diameter	1.1" (28mm) @ 16.4 yds (15m)
Operating Temperature	50°F ~ 100°F
Battery	1/3N x 1
Battery Operating Time	2 hrs
Laser Beam Lifetime	5000 hrs

Windage/Elevation Adjustment

Adjust windage and elevation accordingly until Point of Impact (POI) is the same as Point of Aim (POA) at your desired zero distance. Once POI is POA your laser is zeroed.

Elevation Adjustment: Use included Allen wrench and turn counterclockwise to move beam downward and vice versa



Windage Adjustment: Use included Allen wrench and turn counterclockwise to move beam to the right and vice versa

Maintenance

- Maintain the metal surface of the laser by removing any dirt or sand with a soft brush to avoid scratching the finish.
- Do not attempt to lubricate any part of the laser.
- Do not disassemble the laser other than replacing the battery. Do not loosen or remove screws or parts. Any such or similar actions will void the warranty.
- Servicing the laser is only to be handled by authorized factory trained technicians.

The Best Never Rest Warranty - Lifetime

Leapers, Inc. warrants that all UTG & UTG PRO products conform to published specifications and are free from defects in material and workmanship. We will repair or replace defective products for the duration of the product's life span. Our dedicated and professional in-house customer service team will go above and beyond to make things right and provide the best in-class customer service experience you expect to receive.

Our warranty does not extend to products damaged from misuse, accidental damage, negligence, natural disasters/accidents, or unauthorized repair or alteration.

For warranty service, please submit your inquiry by visiting our customer service page on our website at www.leapers.com or give us a call at 734-542-1500. A Return Authorization Number (RMA) must be assigned before returning any products for warranty service.

5

Disclaimer and Limitation of Liability

Leapers is pleased to offer suggestions of the use of its products, however Leapers neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by Leapers, whether verbal or written.

EXCEPT FOR THE EXPRESS WRITTEN WARRANTY SPECIFICALLY SET FORTH ABOVE, ALL EXPRESS AND IMPLIED REPRESENTATIONS AND WARRANTIES ARE HEREBY DISCLAIMED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, NON-INTERFERENCE, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR WARRANTY OF ACCURACY OF ANY INFORMATION PROVIDED WHETHER WRITTEN OR ORAL. ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING, LAW, USAGE OR TRADE PRACTICE ARE HEREBY EXPRESSLY EXCLUDED TO THE EXTENT ALLOWED BY LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO ONE YEAR. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

UNDER NO CIRCUMSTANCES IS LEAPERS, OR ITS SUPPLIERS OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING EVEN IF INFORMED OF THEIR POSSIBILITY: 1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; 2) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR 3) LOST PROFITS, BUSINESS REVENUE, GOODWILL, OR ANTICIPATED SAVINGS. SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.