

TACTICAL HANDHELD FLASHLIGHT

U n l e a s h T h e G l o w



NEW GEN

5
FUNCTIONS

TACTICAL HANDHELD FLASHLIGHT

U n l e a s h T h e G l o w

OWNER'S MANUAL

For Model: LT-ELS216
 LT-ELS268
 LT-ELS338
 LT-ELF240

US Made CREE LED Module with Optimal Illumination Quality



CAUTION!

If you need to mount the flashlight onto a firearm, make sure firearm is not loaded before installation. Remove magazine and examine chamber. Use safe handling procedures at all times.

SwatForce flashlights produce substantial heat during operation. Do not leave activated flashlight unattended. Do not set activated flashlight face down. Do not place activated flashlight against combustible material or material that could be damaged by heat. Do not hold bezel or lens of activated flashlight against any portion of human body. Keep away from children.

Ensure that the flashlight cannot be turned on when stored or being transported. If the lamp is activated while in a case or any container, the lamp could overheat and cause damage to surrounding materials.

Do not touch a hot lamp assembly. Allow it to cool before handling. Avoid touching reflector surface. Always wear safety glasses when handling.

Examine battery quality and appearance before use each time and make sure that there is no leaking or any deformation. Dispose appropriately if there is a problem.

The batteries are pre-charged by the manufacturer, and cannot be recharged. Recharging can cause battery leakage or, in some cases, high-pressure rupture. Inadvertent charging can occur if a battery is installed backwards.

Install batteries by aligning the + and – signs marked on the battery with the + and – signs marked on the battery chamber in the light.

Turn off the light when not in use to conserve battery power.

Make sure to turn off the light or disconnect the pressure switch before inspecting bulb and battery if the light cannot be turned on.

Keep batteries cool and dry. Always remove batteries from light after use. Leaving battery in the light without use for long period of time may cause damage or danger.

Never use non-rechargeable and rechargeable batteries together in a light. Always replace batteries with the exact type and size specified for the light.

Always replace the whole set of batteries at the same time. Never mix new and used batteries in the same light.

Never deliberately short circuit batteries. Prolonged short circuit will cause the battery to lose energy and result in significant temperature increase.

Do not carry light with batteries installed in the car trunk while driving.

Keep battery compartment clean and keep any metallic object away from the battery.

Lithium batteries can explode or cause burns if disassembled, shorted, recharged, exposed to water, fire, or high temperatures. Do not place loose batteries in a pocket, purse, or other container containing metal objects. Do not mix new with used batteries or mix required batteries with other types of battery. Do not store batteries with hazardous or combustible materials. Store in cool, dry, ventilated area. Follow applicable laws and regulations for disposal.

LT-ELS216 Component Illustration



LT-ELS268 Component Illustration



LT-ELS338 Component Illustration



LT-ELF240 Component Illustration



Specifications

Item Number			LT-ELF240	LT-ELS216	LT-ELS268	LT-ELS338
Bulb Type			40mm LED IRB*	16mm LED IRB*	26mm LED IRB*	37mm LED IRB*
Voltage			6V	6V	6V	9V
Weight with Batteries			9.6oz (272g)	3.5oz (99g)	5.9oz (166g)	9.8oz (277g)
Main Body Diameter			1.07" (27mm)	0.79" (20mm)	1" (25.4mm)	1.07" (27mm)
Length			7.13" (181.1mm)	5" (127mm)	5.5" (139.6mm)	7.13" (181.1mm)
Battery/Qty			CR123A x 2	CR123A x 2	CR123A x 2	CR123A x 3
Lanyard			N/A	Included	Included	Included
Focus			Preset	Preset	Preset	Preset
Brightness	High	Max. Lumen	200 lumens	120 lumens	150 lumens	200 lumens
		Battery Operating Time	1.5hrs+	2hrs+	2hrs+	1.5hrs+
	Medium	Max. Lumen	100 lumens	60 lumens	80 lumens	100 lumens
		Battery Operating Time	3hrs+	5hrs+	5hrs+	3hrs+
	Low	Max. Lumen	50 lumens	20 lumens	30 lumens	50 lumens
		Battery Operating Time	6hrs+	12hrs+	10hrs+	6hrs+

Note: Please refer to page 7 for brightness specifications.

*IRB - Integrated Reflector and Bulb

Installation & Operation

Battery Installation

1. Unscrew the End Cap, install CR123A lithium batteries following directions in (Fig. 1).
2. Screw the End Cap back to the original position.



On-off Switch Operation

1. Tighten the End Cap.
2. Press and release the Push-button to turn on or off the Light (Fig. 2).



5-function Operation

To change between functions, turn off the light and turn it back on within 2 seconds. The unit will rotate to the next function.

The 5-function IRB also has a memory feature. Turn on the unit and it will light up at the last function used.

Flashlight Lanyard Applications

Please refer to the enclosed lanyard application illustrations for your flashlight model.

5-function Sequence

HIGH
BRIGHTNESS



MEDIUM
BRIGHTNESS



LOW
BRIGHTNESS



STROBE



SOS SIGNAL



Replacement Parts

Contact your flashlight distributor for the following replacement parts:

Item Number	Light Bulb	Battery	Pressure Switch	Mount	Lanyard
LT-ELS216	IRB-ELS016	BAT-LIT880	N/A	RG-LS269	PVC-FLYD20
LT-ELS268	IRB-EL026, IRB-ELS026	BAT-LIT880	TL-PSTL099-A	RG-FL860, RGWM-25L2, RQ2W1104	PVC-FLYD80
LT-ELS338	IRB-EL037, IRB-ELS037	BAT-LIT880	TL-PSTL099-A	MNT-EL338DK	PVC-FLYD80

Accessories Reference Table

*IRB - Integrated Reflector and Bulb

						
IRB-ELS016	IRB-EL026	IRB-ELS026	IRB-EL037	IRB-ELS037	BAT-LIT880	TL-PSTL099-A
16mm 6V 5-function LED IRB*	26mm 6V LED IRB*	26mm 6V 5-function LED IRB*	37mm 9V LED IRB*	37mm 9V 5-function LED IRB*	2PC Set of CR123A Lithium Battery	Deluxe Pressure Switch
						
RQ2W1104	RG-LS269	RG-FL860	RGWM-25L2	MNT-EL338DK	PVC-FLYD20	PVC-FLYD80
Max Strength Quick Detach Picatinny Rings (Sold by Pair)	Slide-on Weaver Ring Clamping Dia. 19.6-20.2mm	Slide-on Weaver Ring Clamping Dia. 16mm-23mm	Premium 1" Weaver Style Rings (Sold by Pair)	1.07" Flashlight Tube with Integrated Picatinny/Weaver Mounting Deck	Heavy Duty Lanyard Length: 7.9" (20cm)	Heavy Duty Lanyard Length: 31.5" (80cm)

IRB* Replacement

1. Unscrew the Flashlight Front Head or Len Cap counterclockwise to expose the IRB*.
2. Pull out IRB.
3. Follow the above steps in reverse order to install a new IRB.



*IRB - Integrated Reflector and Bulb

Maintenance

1. Maintain the metal surface of the flashlight by removing any dirt or sand with a soft brush to avoid scratching the finish.
2. Store the flashlight in a cool dry place when not in use. Be careful to avoid contact with acid, alkaline or corrosive chemicals.
3. Replace the batteries in your flashlight every few months if it was not used for long period of time. This insures good working batteries for your light and prevents battery leakage.
4. Keep a fresh package of batteries next to your flashlight. This gives you back-up power for your light.
5. Do not store your flashlight in high temperatures. This would damage your flashlight and may result in battery leakage.
6. Do not put the flashlight head against any surface especially paper or human skin for it has heat and may result in accidents.
7. Do not leave your flashlight under the seat in your car, or in direct sunlight to avoid over-heating.
8. Do not attempt to lubricate any part of the flashlight.
9. Do not disassemble the flashlight other than replacing light bulb or pressure switch. Do not loosen or remove screws or parts. Any such or similar actions will void the warranty.



Make sure the flashlight is completely cool before replacing the IRB.

The Best Never Rest Warranty - Lifetime

Leapers, Inc. warrants that all UTG & UTG PRO products conform to published specifications and are free from defects in material and workmanship. We will repair or replace defective products for the duration of the product's life span. Our dedicated and professional in-house customer service team will go above and beyond to make things right and provide the best in-class customer service experience you expect to receive.

Our warranty does not extend to products damaged from misuse, accidental damage, negligence, natural disasters/accidents, or unauthorized repair or alteration.

For warranty service, please submit your inquiry by visiting our customer service page on our website at www.leapers.com or give us a call at 734-542-1500. A Return Authorization Number (RMA) must be assigned before returning any products for warranty service.

Disclaimer and Limitation of Liability

Leapers is pleased to offer suggestions of the use of its products, however Leapers neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by Leapers, whether verbal or written.

EXCEPT FOR THE EXPRESS WRITTEN WARRANTY SPECIFICALLY SET FORTH ABOVE, ALL EXPRESS AND IMPLIED REPRESENTATIONS AND WARRANTIES ARE HEREBY DISCLAIMED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, NON-INTERFERENCE, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR WARRANTY OF ACCURACY OF ANY INFORMATION PROVIDED WHETHER WRITTEN OR ORAL. ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING, LAW, USAGE OR TRADE PRACTICE ARE HEREBY EXPRESSLY EXCLUDED TO THE EXTENT ALLOWED BY LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO ONE YEAR. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

UNDER NO CIRCUMSTANCES IS LEAPERS, OR ITS SUPPLIERS OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING EVEN IF INFORMED OF THEIR POSSIBILITY: 1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; 2) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR 3) LOST PROFITS, BUSINESS REVENUE, GOODWILL, OR ANTICIPATED SAVINGS. SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.